

### 3 Ton Badland – Drop In & Roll On Mount Instructions

Note: Read instructions before installing. The Roll On style mounts are shown, but the steps are the same for Drop In style mounts as well.

**Step 1:** Left pic. below - Place mounts in desired location with tabs to outside. Drop jack on for test fit and mark the mount locations. Remove jack and drill bolt holes. Install cable lock now if desired, as shown with numbers next to and laying under mount. Loosely install mounts with screws or bolts, place jack on for final alignment then remove and tighten bolts.

**Step 2:** Right pic. below – Bend tabs using adjustable wrench as pictured. Start bend about 1/8” - 1/4” away from relief cuts in mount. Tabs should be same width as mount peak.

**Step 3:** Right pic. below – For storing handles under mount. Cut included rubber edge molding to 2¼” lengths and install as shown.



**Step 4:** Left pic. below - Handle mod. - Remove a section of foam rubber from lower jack handle and install on upper jack handle. Cut around handle a few inches in, then slide foam rubber off of handle. This will hold both handles tight with jack on top.

**Step 5:** Right pic. below – Roll or drop the jack on mounts. Lift front of jack to store handles underneath. Lace cable lock under and around handle pivot as shown. Attach ratchet strap, one long strap can be doubled up as shown.

