

Jack Extension Holder Instructions

These are a new product that we have been refining and perfecting to achieve a snug hold and good impact durability. Under normal circumstances this should last a lifetime, however if you break it or have an issue let us know.

Step 1: Remove foam from handle as necessary, some can be left on if desired. A blast of air will usually get it to break free and slide right off.

Step 2: Slide holders over jack handle and snug up. Clip extensions on holders to position, start with the top holder. We recommend leaving 11" extension $\frac{1}{4}$ " above the jack base. Then position the bottom holder slightly above the end of 6" extension.

Step 3: Rotate for final alignment and tighten clamps. We recommend to tighten jack handle and have the extensions on either side. This helps for keeping clearance from vehicle and lets you know where tight is too.

Step 4: When the jack handle is loose the extra weight of the extensions can let the handle drop easier than before. We recommended to leave the handle tight if storing with handle attached.



Jack Extension Holder Instructions

These are a new product that we have been refining and perfecting to achieve a snug hold and good impact durability. Under normal circumstances this should last a lifetime, however if you break it or have an issue let us know.

Step 1: Remove foam from handle as necessary, some can be left on if desired. A blast of air will usually get it to break free and slide right off.

Step 2: Slide holders over jack handle and snug up. Clip extensions on holders to position, start with the top holder. We recommend leaving 11" extension $\frac{1}{4}$ " above the jack base. Then position the bottom holder slightly above the end of 6" extension.

Step 3: Rotate for final alignment and tighten clamps. We recommend to tighten jack handle and have the extensions on either side. This helps for keeping clearance from vehicle and lets you know where tight is too.

Step 4: When the jack handle is loose the extra weight of the extensions can let the handle drop easier than before. We recommended to leave the handle tight if storing with handle attached.



Jack Extension Holder Instructions

These are a new product that we have been refining and perfecting to achieve a snug hold and good impact durability. Under normal circumstances this should last a lifetime, however if you break it or have an issue let us know.

Step 1: Remove foam from handle as necessary, some can be left on if desired. A blast of air will usually get it to break free and slide right off.

Step 2: Slide holders over jack handle and snug up. Clip extensions on holders to position, start with the top holder. We recommend leaving 11" extension $\frac{1}{4}$ " above the jack base. Then position the bottom holder slightly above the end of 6" extension.

Step 3: Rotate for final alignment and tighten clamps. We recommend to tighten jack handle and have the extensions on either side. This helps for keeping clearance from vehicle and lets you know where tight is too.

Step 4: When the jack handle is loose the extra weight of the extensions can let the handle drop easier than before. We recommended to leave the handle tight if storing with handle attached.

